
DNP3 Client (DCA) for the Multifunction Controller Platform

Conformance Statement

Associated with NTEK-A023M-0CS

Version 2.00 Revision 1

Associated Software Release: Version 2.60



COPYRIGHT NOTICE

© 2019-2021, General Electric Company. All rights reserved.

The Software Product described in this documentation may only be used in accordance with the applicable License Agreement. The Software Product and Associated Material are deemed to be "commercial computer software" and "commercial computer software documentation," respectively, pursuant to DFAR Section 227.7202 and FAR Section 12.212, as applicable, and are delivered with Restricted Rights. Such restricted rights are those identified in the License Agreement, and as set forth in the "Restricted Rights Notice" contained in paragraph (g) (3) (Alternate III) of FAR 52.227-14, Rights in Data-General, including Alternate III (June 1987).

If applicable, any use, modification, reproduction release, performance, display or disclosure of the Software Product and Associated Material by the U.S. Government shall be governed solely by the terms of the License Agreement and shall be prohibited except to the extent expressly permitted by the terms of the License Agreement.

The information contained in this online publication is the exclusive property of General Electric Company, except as otherwise indicated. You may view, copy and print documents and graphics incorporated in this online publication (the "Documents") subject to the following: (1) the Documents may be used solely for personal, informational, non-commercial purposes; (2) the Documents may not be modified or altered in any way; and (3) General Electric Company withholds permission for making the Documents or any portion thereof accessible via the internet. Except as expressly provided herein, you may not use, copy, print, display, reproduce, publish, license, post, transmit or distribute the Documents in whole or in part without the prior written permission of General Electric Company. If applicable, any use, modification, reproduction, release, performance, display, or disclosure of the Software Product and Associated Material by the U.S. Government shall be governed solely by the terms of the License Agreement and shall be prohibited except to the extent expressly permitted by the terms of the License Agreement.

The information contained in this online publication is subject to change without notice. The software described in this online publication is supplied under license and may be used or copied only in accordance with the terms of such license.

TRADEMARK NOTICES

GE and



(%) are trademarks and service marks of General Electric Company.

* Trademarks of General Electric Company.

Other company or product names mentioned in this document may be trademarks or registered trademarks of their respective companies.

Contents

1.	NP3 Client Application on MCP - Device Profile Document)
	••	
	1 Profile of Normal Operation)

General

Tables

Table 1: DNP3 Subset Sent by the Client under normal operation	8
Table 2: DNP3 Subset Implemented by the Client	11

NTEK-A023M-0CS-2.00-1

1. DNP3 Client Application on MCP – Device Profile Document

This document contains the Device Profile for the DNP3 Client Application on the MCP. Note that this Profile applies to the Client Application, not to the entire MCP.

DNP3								
Device Profile	e Document							
Vendor Name: GE Grid Solutions								
Device Name: MCP DNP3 Client (both Serial and LAN	1).							
Highest DNP Level Supported:	Device Function:							
For Requests 2	■ Master □ Slave							
For Responses 3								
Notable objects, functions, and/or qualifiers supported in complete list is described in the attached table):	addition to the Highest DNP Levels Supported (the							
= Accepts many more qualifiers than specified in	Level 3.							
= Can issue Enable Unsolicited Response for Clas	is 1, 2 and 3 upon receipt of Null Unsolicited Response.							
Maximum Data Link Frame Size (octets):	Maximum Application Fragment Size (octets):							
Transmitted292	Transmitted100 to 65535							
Received292	Received100 to 65535							
Maximum Data Link Re-tries:	Maximum Application Layer Re-tries:							
□ None	□ None							
☐ Fixed at	☐ Fixed at							
☑ Configurable, range 0 to 255 (config file)	区 Configurable, range 0 to 255 (config file)							
Requires Data Link Layer Confirmation:								
□ Never								
□ Always								
☐ Sometimes If 'sometimes', when?								
☑ Configurable If 'configurable', how? Using	a config file							
Requires Application Layer Confirmation:								
⊠ Never								
☐ Always (not recommended)								
☐ When reporting Event Data (Slave devices only)								
☐ When sending multi-fragment responses (Slave devices only)								
☐ Sometimes If 'sometimes', when?								
☐ Configurable If 'configurable', how?								
Timeouts while waiting for:								
Data Link Confirm □ None □ Fixed at								
□ Variable 🗷 Configurable								

General NTEK-A023M-0CS-2.00-1 5

	DNP3						
	Device Profile	Document					
Complete Appl. Fragment 🔲 No	one 🗆 Fixed at						
🗖 Variable 🗷 Co	onfigurable						
Application Confirm 🗷 No	one 🗆 Fixed at						
□ Variable □ Co	onfigurable						
Complete Appl. Response 🗷 No	one 🗖 Fixed at						
□ Variable □ Co	onfigurable						
Others							
Sends/Executes Control Operations	5:						
WRITE Binary Outputs	■ Never	□ Always					
	☐ Sometimes	☐ Configurable					
SELECT/OPERATE	□ Never	□ Always					
	■ Sometimes	□ Configurable					
DIRECT OPERATE	□ Never	□ Always					
	■ Sometimes	□ Configurable					
DIRECT OPERATE - NO ACK	□ Never	□ Always					
	■ Sometimes	☐ Configurable					
Count > 1	□ Never	□ Always					
	■ Sometimes	☐ Configurable					
Pulse On	□ Never	□ Always					
	■ Sometimes	☐ Configurable					
Pulse Off	□ Never	□ Always					
	■ Sometimes	□ Configurable					
Latch On	□ Never	□ Always					
	■ Sometimes	☐ Configurable					
Latch Off	□ Never	□ Always					
	■ Sometimes	☐ Configurable					
Queue	■ Never	□ Always					
	☐ Sometimes	☐ Configurable					
Clear Queue	■ Never	□ Always					
	☐ Sometimes	□ Configurable					
	figured to send all con	Il software executing and the configuration of the trols as Direct Operate, SBO, or Direct Operate No Ack.					
Reports Binary Input Change Event variation requested (Slave Only):	s when no specific	Reports time-tagged Binary Input Change Events when no specific variation requested:					
■ Never		■ Never					
☐ Only time-tagged		☐ Binary Input change with time					
☐ Only non time-tagged	d	☐ Binary Input change with Relative					
☐ Configurable to send	both, one	time					
or the other (attach ex	(planation)	☐ Configurable (attach explanation)					

DNI	DNP3						
Device Profile	e Document						
Master Expects Binary Input Change Events: ☑ Either time-tagged or non-time-tagged for a single event							
□ Both time-tagged and non-time-tagged for a single event□ Configurable (attach explanation)							
Sends Unsolicited Responses (Slave Only):	Sends Static Data in Unsolicited Responses (Slave Only):						
 ☑ Never ☐ Configurable (attach explanation) ☐ Only certain objects ☐ Sometimes (attach explanation) ☐ ENABLE/DISABLE UNSOLICITED Function codes Supported 	☑ Never☐ When Device Restarts☐ When Status Flags ChangeNo other options are permitted.						
Sends Multi-Fragment Responses (Slave Only):	☐ Yes 🗷 No						

The Client sends to remote devices the subset of DNP3 objects, variations, qualifiers and function codes listed in Table 1.

General NTEK-A023M-0CS-2.00-1 **7**

Table 1: DNP3 Subset Sent by the Client under normal operation

	O	bject	Request					
Obj	Var	Description	Function Codes	Qual Codes (Hex)	Sent			
1	0	Binary Input [All variations]	READ (1)	06	On a periodic basis as configured by the user			
2	0	Binary Input Change [All variations]	READ (1)	06	On a periodic basis as configured by the user			
3	0	Double-Bit Binary Input [All variations]	READ (1)	06	On a periodic basis as configured by the user			
4	0	Double-Bit Binary Input Change [All variations]	READ (1)	06	On a periodic basis as configured by the user			
10	1	Binary Output Status	READ (1)	06	On a periodic basis as configured by the user Sent immediately following the issue of a CROB command. Also sent (according to user config) if LOCAL IIN detected.			
12	1	Control Relay Output Block	SELECT (3) OPERATE (4) DIRECT OPERATE (5) DIRECT OPERATE - NO ACK (6)	28	Only on demand.			
20	0	Binary Accumulators [All Variations]	READ(1)	06	On a periodic basis as configured by the user			
21	0	Frozen Accumulators [All Variations]	READ(1)	06	On a periodic basis as configured by the user			
22	0	Accumulator Change Events [All Variations]	READ(1)	06	On a periodic basis as configured by the user			
23	0	Frozen Accumulator Change Events [All Variations]	READ(1)	06	On a periodic basis as configured by the user			
30	0,1,2 ,5,6	Analog Inputs [All Variations, 16 Bit, 32 Bit, Float, Long Float]	READ(1)	06	On a periodic basis as configured by the user			

	C	bject		Requ	est			
Obj	Var	Description	Function Codes	Qual Codes (Hex)	Sent			
32	0	Analog Input Change Events [All Variations]	READ(1)	06	On a periodic basis as configured by the user			
40	0,1,2	Analog Outputs [All Variations, 16 Bit, 32 Bit]	READ(1)	06	On a periodic basis as configured by the user			
50	1	Time and Date	WRITE (2)	07 quant = 1	Regularly scheduled and/or in response to TIME SYNC REQUIRED IIN.			
60	1	Class 0 Data	READ (1) ENABLE UNSOLICITED (20) DISABLE UNSOLICITED (21)	06	READ sent periodically, in response to various IINs. ENABLE/DISABLE UNSOLICITED sent as configured upon startup, and on receipt of a NULL Unsolicited Response			
60	2	Class 1 Data	READ (1)	06	On periodic basis, to retrieve a configured number of class 1 events.			
				06	On periodic basis, in response to various IINs.			
			ENABLE UNSOLICITED (20) DISABLE UNSOLICITED (21)	06	ENABLE/DISABLE UNSOLICITED sent as configured upon startup, and on receipt of a NULL Unsolicited Response			
60	3	Class 2 Data	READ (1)	08	On periodic basis, to retrieve a configured number of class 2 events.			
				06	On periodic basis, in response to various IINs.			
			ENABLE UNSOLICITED (20) DISABLE UNSOLICITED (21)	06	ENABLE/DISABLE UNSOLICITED sent as configured upon startup, and on receipt of a NULL Unsolicited Response			
60	4	Class 3 Data	READ (1)	08	On periodic basis, to retrieve a configured number of class 3 events.			
				06	On periodic basis, in response to various IINs.			
			ENABLE UNSOLICITED (20) DISABLE UNSOLICITED (21)	06	ENABLE/DISABLE UNSOLICITED sent as configured upon startup, and on receipt of a NULL Unsolicited Response			
80	1	Internal Indication	WRITE (2)	00	On receipt of a response containing the DEVICE RESTART bit set.			

General NTEK-A023M-0CS-2.00-1 9

	0	bject	Request				
Obj Var Description		Description	Function Codes Qual Codes (Hex) Sent.		Sent		
No ok	No object		DELAY MEASUREMENT (23)	None	On demand. If Auto Time Synchronization Enable is True it will also be sent in response to the TIME SYNC NEEDED IIN.		

1.1 Profile of Normal Operation

The following table describes all the DNP3 objects, function codes, and qualifiers sent or received by the DNP3 Client software during normal operation. Each line of the table lists an object variation.

If the *Request* columns are blank, the Client does not send that object variation to remote devices. If the *Request* columns are non-blank, they indicate that the Client sends that object variation, with the specified function codes, under certain conditions.

The Sent When column describes these conditions, as follows:

D: The Client sends the request when a local software application **Demands** it do so.

O: The Client sends the request following a previous **Output** request.

I : The Client sends the request as a result of an **Internal Indication** from the remote device.

A : The Client sends the request **Automatically** as a part of its own operation, e.g. at start-up time, or if the local time changes.

P: The Client sends the request **Periodically**.

(C) : Following any of the above indicates the Client can be **Configured** to perform or not perform the request in this manner.

If the *Response* columns are blank, the Client does not accept the object variation and will discard any message containing that object variation. If the *Response* columns are non-blank, the Client accepts the object variation in responses, provided the remote device uses a valid function code and qualifier.

A " \checkmark " in the *Uses* column means that the Client stores or forwards the data; otherwise, it ignores the object when parsing.

Table 2: DNP3 Subset Implemented by the Client

		Object		Request		Res	ponse
Obj	Var	Description	Func Codes (Dec)	Qual Codes (Hex)	Sent When 	Func Codes (Dec)	Uses
1	0	Binary Input - All Variations	1	06	P(c)		
1	1	Binary Input – Packed Format				129, 130	✓
1	2	Binary Input With Status				129, 130	✓
2	0	Binary Input Change - All Variations	1	06	P(c)		
2	1	Binary Input Change Without Time				129, 130	✓
2	2	Binary Input Change With Time				129, 130	✓
2	3	Binary Input Change With Relative Time				129, 130	√
3	0	Double-Bit Binary Input - All Variations	1	06	P(c)		
3	1	Double-Bit Binary Input – Packed Format				129, 130	✓
3	2	Double-Bit Binary Input With Status				129, 130	✓
4	0	Double-Bit Binary Input Change - All Variations	1	06	P(c)		
4	1	Double-Bit Binary Input Change Without Time				129, 130	√
4	2	Double-Bit Binary Input Change With Time				129, 130	√
4	3	Double-Bit Binary Input Change With Relative Time				129, 130	✓
10	0	Binary Output - All	1	06	P(c), I(c), O	129	
10	1	Binary Output					
10	2	Binary Output Status				129, 130	✓
12	0	Control Block - All Variations					
12	1	Control Relay Output Block	3, 4, 5, 6	28	D (c)	129	✓
12	2	Pattern Control Block					
12	3	Pattern Mask					
20	0	Binary Counter - All Variations	1, 7	06	P (C), O		
20	1	32-Bit Binary Counter				129, 130	√
20	2	16-Bit Binary Counter				129, 130	✓
20	3	32-Bit Delta Counter				129, 130	✓

		Object		Request		Res	ponse
Obj	Var	Description	Func Codes (Dec)	Qual Codes (Hex)	Sent When 	Func Codes (Dec)	Uses
20	4	16-Bit Binary Counter				129, 130	✓
20	5	32-Bit Binary Counter Without Flag				129, 130	✓
20	6	16-Bit Binary Counter Without Flag				129, 130	~
20	7	32-Bit Delta Counter Without Flag				129, 130	✓
20	8	16-Bit Delta Counter Without Flag				129, 130	✓
21	0	Frozen Counter - All Variations	1	06	P (C), O		
21	1	32-Bit Frozen Counter				129, 130	✓
21	2	16-Bit Frozen Counter				129, 130	✓
21	3	32-Bit Frozen Delta Counter				129, 130	✓
21	4	16-Bit Frozen Delta Counter				129, 130	✓
21	5	32-Bit Frozen Counter With Time of Freeze				129, 130	✓
21	6	16-Bit Frozen Counter With Time of Freeze				129, 130	✓
21	7	32-Bit Frozen Delta Counter With Time of Freeze				129, 130	✓
21	8	16-Bit Frozen Delta Counter With Time of Freeze				129, 130	✓
21	9	32-Bit Frozen Counter Without Flag				129, 130	✓
21	10	16-Bit Frozen Counter Without Flag				129, 130	✓
21	11	32-Bit Frozen Delta Counter Without Flag				129, 130	✓
21	12	16-Bit Frozen Delta Counter Without Flag				129, 130	✓
22	0	Counter Change Event - All Variations	1	06	P(c)		
22	1	32-Bit Counter Change Event Without Time				129, 130	✓
22	2	16-Bit Counter Change Event Without Time				129, 130	✓
22	3	32-Bit Delta Counter Change Event Without Time				129, 130	✓
22	4	16-Bit Delta Counter Change Event Without Time				129, 130	✓
22	5	32-Bit Counter Change Event With Time				129, 130	✓

		Object		Request		Response		
Obj	Var	Description	Func Codes (Dec)	Qual Codes (Hex)	Sent When 	Func Codes (Dec)	Uses	
22	6	16-Bit Counter Change Event With Time				129, 130	✓	
22	7	32-Bit Delta Counter Change Event With Time				129, 130	√	
22	8	16-Bit Delta Counter Change Event With Time				129, 130	✓	
23	0	Frozen Counter Event - All Variations	1	06	P(c)			
23	1	32-Bit Frozen Counter Event Without Time				129, 130	✓	
23	2	16-Bit Frozen Counter Event Without Time				129, 130	✓	
23	3	32-Bit Frozen Delta Counter Event Without Time				129, 130	✓	
23	4	16-Bit Frozen Delta Counter Event Without Time				129, 130	✓	
23	5	32-Bit Frozen Counter Event With Time				129, 130	√	
23	6	16-Bit Frozen Counter Event With Time				129, 130	✓	
23	7	32-Bit Frozen Delta Counter Event With Time				129, 130	✓	
23	8	16-Bit Frozen Delta Counter Event With Time				129, 130	✓	
30	0	Analog Input - All Variations	1	06	P(c) O(c)			
30	1	32-Bit Analog Input	1	06	P(c)	129, 130	✓	
30	2	16-Bit Analog Input	1	06	P(c)	129, 130	✓	
30	3	32-Bit Analog Input Without Flag				129, 130	√	
30	4	16-Bit Analog Input Without Flag				129, 130	✓	
30	5	32-Bit Floating Point Analog Input	1	06	P(c)	129, 130	✓	
30	6	64-Bit Floating Point Analog Input	1	06	P(c)	129, 130	✓	
31	0	Frozen Analog Input - All Variations	1	06				
31	1	32-Bit Frozen Analog Input				129, 130		
31	2	16-Bit Frozen Analog Input				129, 130		
31	3	32-Bit Frozen Analog Input With Time of Freeze				129, 130		

		Object		Request		Res	ponse
Obj	Var	Description	Func Codes (Dec)	Qual Codes (Hex)	Sent When 	Func Codes (Dec)	Uses
31	4	16-Bit Frozen Analog Input With Time of Freeze				129, 130	
31	5	32-Bit Frozen Analog Input Without Flag				129, 130	
31	6	16-Bit Frozen Analog Input Without Flag				129, 130	
32	0	Analog Change Event - All Variations	1	06	P(c)		
32	1	32-Bit Analog Change Event Without Time				129, 130	✓
32	2	16-Bit Analog Change Event Without Time				129, 130	✓
32	3	32-Bit Analog Change Event With Time				129, 130	✓
32	4	16-Bit Analog Change Event With Time				129, 130	✓
32	5	32-Bit Floating Point Analog Change Event without Time				129, 130	✓
32	6	64-Bit Floating Point Analog Change Event without Time				129, 130	✓
32	7	32-Bit Floating Point Analog Change Event with Time				129, 130	✓
32	8	64-Bit Floating Point Analog Change Event with Time				129, 130	✓
33	0	Frozen Analog Event - All Variations	1	06			
33	1	32-Bit Frozen Analog Event Without Time				129, 130	
33	2	16-Bit Frozen Analog Event Without Time				129, 130	
33	3	32-Bit Frozen Analog Event With Time				129, 130	
33	4	16-Bit Frozen Analog Event With Time				129, 130	
40	0	Analog Output Status - All Variations	1	06	P(c), O		
40	1	32-Bit Analog Output Status	1	06	P(c)	129, 130	✓
40	2	16-Bit Analog Output Status	1	06	P(c)	129, 130	✓
41	0	Analog Output Block - All Variations					
41	1	32-Bit Analog Output Block					
41	2	16-Bit Analog Output Block					

Object			Request			Response	
Obj	Var	Description	Func Codes (Dec)	Qual Codes (Hex)	Sent When 	Func Codes (Dec)	Uses
50	0	Time and Date - All Variations					
50	1	Time and Date	2	07 where qnty = 1	I (C), P (C)	129, 130	
50	2	Time and Date With Interval				129, 130	
51	0	Time and Date CTO - All Variations					
51	1	Time and Date CTO				129, 130	✓
51	2	Unsynchronized Time and Date CTO				129, 130	✓
52	0	Time Delay - All Variations					
52	1	Time Delay Coarse				129	✓
52	2	Time Delay Fine				129	✓
60	0						
60	1	Class 0 Data	1	06	P (C),		
60	2	Class 1 Data	1	06	P (C), I, O(C)		
60	3	Class 2 Data	1	06	P (C),		
60	4	Class 3 Data	1	06	P (C)		
70	1	File Identifier				129	
80	1	Internal Indications	2	00	1	129, 130	✓
81	1	Storage Object				129, 130	
82	1	Device Profile				129, 130	
83	1	Private Registration Object				129, 130	
83	2	Private Registration Object Descriptor				129, 130	
90	1	Application Identifier					
100	1	Short Floating Point					
100	2	Long Floating Point					
100	3	Extended Floating Point					
101	1	Small Packed Binary-Coded Decimal					
101	2	Medium Packed Binary Coded Decimal					

Object			Request			Response	
Obj	Var	Description	Func Codes (Dec)	Qual Codes (Hex)	Sent When 	Func Codes (Dec)	Uses
101	3	Large Packed Binary_Coded Decimal					
No Object			23		I (C)		

MODIFICATION RECORD

VERSION	REV.	DATE	CHANGE DESCRIPTION
1.00	0	2 nd May, 2019	Created.
2.00	0	20 th October, 2021	Added support for Double-Bit Binary Inputs.
	1	10 th December, 2021	Removed support for Object Groups 31 and 33.